

<b>Decor 600/Ronda : 528.18.XXXX.X</b>		
1	Ceiling plate	X
2	Chimney	X
3	Motor	R520.17.2531.0
4	Quick Fit, Light	R520.17.2506.0
5	Quick Fit, Motor with motor	R520.17.2504.0
5	Quick Fit, Motor ext motor	R520.17.2505.0
6	Finger touch	R520.17.2507.0
7	Cable	R520.17.2516.0
8	Filter	P515.58.0280.0
9	Lamp	P515.55.2000.0

